## W9YA's openGD77 Quick Start and Recommendations

## 01-Jan-2023

## Nomenclature:

- Menu = Green Key
- Sk1 = Upper-most key on left side that is NOT the PTT key (Push to talk).
- Sk2 = Lower-most key on left side that is NOT the PTT key (Push to talk).

# Gotchas:

- TS indicator in the top left of display does not "follow" the codeplug settings for the channel.

The \* key overrides the channel setting if it is pressed.

FIX; 1 - In the Display Options menu (Green button > Options > Display Options > Info = (Set to) BOTH
2 - LONG PRESS the \* key to revert to normal operation.

# <u>Suggested Settings:</u>

- Menu > Options > Radio options >	Scan Mode Scan Dwell	= (Set to)	120ms	HOLD active signal)
- Menu > Options > Display options	> Order > Contact > Info	= (Set to) = (Either) = (Set to)	TA/DB/CT AUTO or Z BOTH	
- Menu > Options > Sound options	<ul><li>&gt; Talker</li><li>&gt; DMR bee</li><li>&gt; RX beep</li><li>&gt; DMR Rx</li></ul>	= (Se	et to) BOT et to) BOT	Н

# Get Outta Trouble:

- Press the Menu key three times to re-load the Channels IF the Menu key is "indexed" to ZONE.

- Turn off and on the radio to re-index the Menu to Zone. (Also re-indexes the Quick-Menu.

#### Key Press Macros:

- Sk1 = Short gives numerical information for channel - Sk1 + Green
  - = Quick Menu (The items in this menu appear nowhere else.)
- Sk2

- Sk2 + \*

- Sk2 + Green = Channel Details display (AND modify) OR Store Option changes
- Sk2 long press = Force to wide FM mode and open squelch
- = Move XMIT TG to received TG (Clear = 3 presses Menu) - Sk2 during rcv
- Sk2 + arrow = Set Power Output (Up & Down - UV380 / Left & Right - GD77)
- Sk2 + channel = Change Zone (Channel Knob - UV380 / Up & Down - GD77)
  - = Toggle mode between Fm and DMR
- Sk2 + # = Select TG from Contact List
- Green = Menu &/or YES
- Green then \* = (From the menu's top level > Press \*) Keypad Lock
- = (From the menu's top level > Press #) PTT Lock - Green then #
- Red = VFO/Channel toggle &/or NO (Exit)
- Up Arrow = Start Scan (Long press)

= Menu

- = Bypass current channel during Scan (Temporary only) - Down Arrow
- \* short press = If FM mode - Toggle Wide and Narrow Mode (short press ONLY)
  - = If DMR mode Force Time slot (toggles between TS1 and TS)
- \* long press = If DMR mode - Turn OFF forced Time slot
- # short press = If FM mode - DTMF entry
  - = If DMR mode TG entry (additonal presses for more options)
- # long press = If FM or DMR mode - reverse duplex channel's RX and TX freqs.
  - = IF VFO mode "Band Scope" mode (see manual for adjustments)

# <u>Additional Help:</u>

- openGD77 manual Usually out of date, but a good overview.
- openGD77 forum @ openGD77.com VERY up to date and searchable !
- Visual "Cheatsheets" above forum, search for "Cheatsheet".
- You Tube Various sources, look for the latest videos. \*\*\* Things change RAPIDLY. Some of the very recent openMDUV380 videos are excellent BTW.

\*\*\* Be sure to play with the Arrows (and Channel Knob) to learn operational choices.

### es vy 73 om's de "baab" w9ya